



BUZZKILL MANUAL



1. Audio out
2. Press in for ground lift
3. Press in for phase inversion*
4. Audio in

*Phase only functional when TX button is pressed in

Buzzkill is designed to defeat ground loops and correct phase issues between multiple amps. Because it requires no power it can be placed at your amp. It can even be mounted permanently inside the back of your amp or kept in your gig bag ready for any situation. For Buzzkill to be effective it is critical it's the very last thing before your signal hits your amp.

When running a multi-amp setup with ground loop and/or phase issues, you will need one less Buzzkill than the number of amps you're using. A three amp setup will require two Buzzkills, and a two amp setup will require one.

Buzzkill can also be used to fix ground loop issues when using multiple amps with FX loops. Use Buzzkills on the input, FX send and FX return of one amp.

How to connect Buzzkill

Connect your pedal board to Buzzkill's input with the cable you would normally connect directly to your amp. Then connect Buzzkill's output to the input of your amp.



Specs

Buzzkill requires no power.

Dimensions (incl. all jacks and switches):

112mm wide x 64mm deep x 32mm high

Weight: 165 grams